

How to Remove the Furling Drum

Open the lower inspection covers and remove the tack shackle. This will disconnect the furling drum from the furling foil.

Remove Sail.

Secure the foil by hitching with the halyard. Ease foil out of drum foil connector.

Remove the machine screws holding the furling mechanism to the mast. These are located two at the top of the drum and two at the bottom of the drum. On some models there will be two additional screws or rivets on the side of the mast to be removed.

Using a large screwdriver, lever the furling drum away from the mast at the bottom end. Then pull drum down and out of the mast.

